

PERRIN

PERFORMANCE

Pre-Filter for Cone Filters

120711

Thank you for purchasing the PERRIN Pre-Filter for your cone filter. Please read through all the instructions before performing the installation.

WARNING: This part is designed, manufactured, and sold solely for use on off-road and racing vehicles not controlled by federal and or local Emissions laws. It is not intended for use on vehicles that operate on public streets and highways. Use of this part on emissions controlled vehicles may be in violation of federal or local law! ASMC, LTD. is not responsible for any damages as a result of misuse of this part. Check your local laws prior to use or installation.

SPECIAL NOTES:

- This Pre-Filter may require that some of your intake system is removed. If this is the case, follow the instructions provided with intake system to remove filter from car.
- It's not a bad idea to clean filter before installation. Make sure to use a "Foam Filter Cleaning Kit" which can be found on our website.
- Keep in mind, this Pre-Filter is water resistant, not water proof. If you find yourself driving through a puddle that can submerge your filter in water, this can cause engine damage. This pre-filter is designed to protect against rain and small water droplets (and dirt) getting ingested into the filter.
- Using a water proofing spray-on like Scotch Guard is not a bad idea from time to time. Making this part of your winter maintenance isn't a bad idea.
- Cleaning your Pre-Filter should be done every time you clean your filter. This could be as simple as shaking off the debris, or rinsing it in water. If heavier cleaning is needed, this should be done with a very light dish detergent. Something like Simple Green, or water based cleaner is best. With proper care, the pre-filter will last a long time.

Parts Included with PERRIN Pre-Filter:

- (1) PERRIN Black Pre-Filter

Installation

1. Locate filter on vehicle and determine if filter needs to be removed. If it needs to be removed, follow instructions to remove from car.
2. Open end of pre-filter and place over filter. Stretch all the way down to base of filter.
3. Reinstall filter if removed earlier.
4. Proceed with normal filter cleaning schedule of 1 year or 10,000 miles.

FOR QUESTIONS & COMMENTS PLEASE CONTACT

TECH@PERRINPERFORMANCE.COM

503-693-1702

Live Chat with us on our website