

Installation Guide

Compression Rod Bushing

Z 5207

Suits: Nissan 350Z

(Always refer to the current catalogue for complete application listings)

N.B: This installation guide should be used in conjunction with the workshop manual.

Step 1



Step 2



Step 3



Step 4



Step 1: Raise the vehicle on a lift or alternatively jack the vehicle up and support on jacking stands. Remove the lower splash tray cover and proceed to remove the lower cradle assembly to gain access to the compression rod. Remove the compression rod cotter pin and using a suitable ball joint separating tool press the joint out of the wheel hub assembly.

Step 2: Place the compression rod on a suitable pressing plate. Proceed to press the steel cased OEM bushing out of the rod.

Note: Ensure the compression rod bore is free of sharp edges & burrs. Repair or replace as required.

Step 3: Install the supplied bushings into the compression rod ensuring bushing is free of grease.

Step 4: Using the grease supplied in the kit, apply a liberal amount of grease into the bore of the bushing.